



MARINE ALIGNMENT

AUTOBALLAST

Let Autoballast calculate the most optimal ballast condition before departure.

Enter your criteria for trim and stability, use your current condition as basis for the calculation or start up from nothing.


Colour coding tells you if the calculated conditions match you criteria.

The most optimal condition calculated by Autoballast can be automatically transferred to Easeacon.

Save planning time - let Autoballast do the calculation.

Save fuel – depart with only the necessary ballast on board.

Developed with our customers world-wide, Easeacon is made in Denmark.



For further information visit
www.marinealignment.com